

FINE CONTROLS (UK) LTD



Fine Controls have been supplying process controls & instrumentation equipment since 1994, & now serves an ever expanding customer base, both in the UK & globally.

We offer a full range of valve & instrumentation products & services, with our product range representing leading technologies & brands:

Flow: Flow Meters & Transmitters, Flow Switches, Flow Control Valves & Batch Control Systems

Temperature: Temperature Probes & Thermowells, Temperature transmitters, Temperature Regulators & Temperature Displays

Level: Level Transmitters & Switches

Pressure: Pressure Gauges & Transmitters, Precision & High Pressure Regulators & I-P Converters, Volume boosters.

Precision Pneumatics: Pressure Regulators, I-P Converters, Volume Boosters, Vacuum Regulators

Valves: Solenoid & Pneumatic Valves, Control Valves & Positioners, Actuated Ball, Globe or Diaphragm Valves & Isolation Valves

Services: Repair, Calibration, Panel Build, System Design & Commissioning

A rotork® Brand
FAIRCHILD



bürkert



SIEMENS



alcon
SOLENOID VALVES

A rotork® Brand



MIDLAND-ACS
A rotork® Brand



Honeywell



Bourdon
Baumer Group



SOLDO
CONTROLS

A rotork® Brand



Fine Controls (UK) LTD, Bassendale Road, Croft Business Park,
Bromborough, Wirral, CH62 3QL UK
Tel: 0151 343 9966
Email: sales@finecontrols.com

INSTRUCTIONS FOR THE INSTALLATION, OPERATION AND MAINTENANCE OF FAIRCHILD MODEL 14 POSITIVE AND NEGATIVE BIAS RELAY

GENERAL INFORMATION

The Fairchild Model 14 bias relay provides for reproduction of a signal pressure plus or minus the spring bias setting.

Specifications

Model 14

Flow capacity 40 SCFM (68 m³/HR) max
(100 psig [7.0 BAR] (700 kPa) supply;
20 psig [1.5 BAR] (150 kPa) set point)


Exhaust capacity 5½ SCFM
(Downstream pressure 5 psig (9.4 m³/HR)
[3.5 BAR] (35 kPa) above set pressure)

Sensitivity ½" (1.25 cm) W.C.

Effect of supply pressure variation	Less than 0.1 psig [0.007 BAR] (.7 kPa) for 100 psig [7.0 BAR] (700 kPa) change
Supply pressure	250 psig [17.0 BAR] (1700 kPa) max.
Signal pressure	150 psig [10.0 BAR] (1000 kPa) max.
Output pressure	150 psig [10.0 BAR] (1000 kPa) max.
Mounting	Pipe or panel
Ambient temperature	-40°F to +200°F -40°C to 93.3°C

PRINCIPLES OF OPERATION


When the knob of the Model 14 is adjusted to a specific setpoint, the range spring exerts a force against the top of the signal diaphragm. Signal pressure P_s also acts against the top of the signal diaphragm. The negative bias spring force acts against the bottom of the signal diaphragm. The combined force is the result of the sum of P_s acting on the signal diaphragm area and the range spring force, minus the negative bias spring force. The resulting output pressure $P_o = P_s + K_1 - K_2$ or $P_s + K$ where P_s is signal pressure, and K is the combined spring constant. This force keeps the relief seat against the relief valve. This condition is achieved only when output pressure reaches the desired setpoint. Until then, the downward force opens the supply valve, allowing supply air to be routed to the outlet port. Downstream (outlet) pressure is transmitted through the aspirator tube to the control chamber where it is sensed on the underside of the control diaphragm. The increase in pressure on the control diaphragm causes the diaphragm assembly to move upward, sliding on the seal tube against the force of the signal pressure acting on the signal diaphragm



and the range spring force acting on the piston, assisted by the negative bias spring force. This force, acting through the pintle, allows the supply valve to throttle, maintaining the output pressure.

When setpoint is reached, the force acting on the bottom of the control diaphragm is in balance with the force acting on the top and bottom of the signal diaphragm.

If downstream pressure increases above setpoint, the increase is transmitted through the aspirator tube to the control diaphragm. The increased pressure acting on the control diaphragm area moves the diaphragm assembly upward, allowing the supply valve to be seated. As the diaphragm assembly continues to move upward, sliding on the seal tube, the relief seat moves away from the relief valve, allowing downstream air to exhaust through the port in the ring spacer. If downstream pressure decreases below set point, the pressure decrease is transmitted through the aspirator tube to the control diaphragm. The decrease in pressure on



SERVICE KIT INSTALLATION

NOTE: Service Kit installation instructions are typical for the standard Model 14 unit. Partial exploded views are included for the Tamperproof Option components.

Also included are Option Tables which identify components which are changed from those of the Standard Model 14 unit. Blank spaces in the table mean that the Standard part is used. The designation NA in the table means that the standard part is not applicable.

FOR MODEL 14

1. Check parts in the EA-12128-(1) service kit against the parts marked with an asterisk in the exploded view and the associated table.
2. Mark Bonnet Assembly (3) and Body (10) so that the relay can be reassembled correctly.
3. Turn Knob Assembly (1) counterclockwise to release compression on Range Spring (5).

FOR MODEL 14 TAMPERPROOF

1. Check parts in the EA-12128-(1) service kit against the parts marked with an asterisk in the exploded view and the associated table.
2. Mark Body (8) and Bonnet Assembly (15) so that they can be reassembled properly.
3. Remove Nut (1A). Turn Range Screw (2B) counterclockwise to release pressure on the Range Spring (5).

FOR ALL MODEL 14 RELAYS



4. Remove six Screws (6) holding the Bonnet Assembly (3) and Diaphragm Assembly (9) to Body (10).
5. Remove Bonnet Assembly (3), Spring Seat (4) and Spring (5) and set aside.
6. Remove Diaphragm Assembly (9) and discard.
7. Remove two Screws (18) holding Retainer Plate (17) and Retainer Cap (19) to Body (10). Set aside Plate (17) and Cap (19).
8. Press out Inner Valve Assembly (15) and Screen (14) from the top of Body (10).
9. Remove four Screws (11) holding Seal Plate Assembly (13) to Body (10). Remove Seal Plate Assembly (13) and set aside. Remove gasket (12) and discard.
10. Using a soft hammer or dowel rod, press out Seat Assembly (29) from Body (10) and discard.
11. Secure Seat Assembly (29) from service kit and place into bottom bore of Body (10) brass end first, until it is sealed in the bottom of the center bore.
12. Turn Body (10) right side up and place Gasket (12) into center well so that indents in the gasket are opposite the four tapped holes.
13. Place Seal Plate Assembly (13) into Body (10) so that aspirator extends into the OUT port of the Body (10) and four holes in Seal Plate Assembly (13) are aligned with four holes in Body (10). Secure Seal Plate Assembly (13) to Body (10) using four Screws (11).

Index	Part No.	Description
1	EB-4124-1	Knob Assembly
1A	EB-7057-2	Cap Nut
2	EB-1120	Lock Nut
2A	EB-1120	Nut
2B	EB-8159-16	Adjusting Screw
3	EB-1895	Bonnet Assembly
4	EB-6053	Spring Seat
5	See Table	Spring
6	EB-1032-32	Screw
*9	See Table	Diaphragm Assembly
10	EB-6050	Body
*11	EB-1032-5	Screw
*12	EB-6053	Gasket
13	EB-1948-1	Seal Plate Assembly
*14	EB-6017	Screen
*15	See Table	Inner Valve Assembly
16	EB-7156	O Ring
17	EB-6027	Retainer Plate
18	EB-1032-6	Screw
19	EB-7136	Retainer Cap
25	EB-8891	Spring
*29	EB-6070	Seat Assembly

*EA-12128 Service Kit components

Range psig	[BAR]	(kPa)	Spring
-15 to 2	[-1.0 to .15]	(15)	EB-6060-20
-15 to 10	[-1.0 to .7]	(70)	EB-6060-30
-15 to 30	[-1.0 to 2.0]	(200)	EB-6060-60
-15 to 100	[-1.0 to 7.0]	(700)	EB-6060-150

- Place screen (14) from service kit into groove of Inner Valve Assembly (15) from service kit. Place Inner Valve Assembly (15) into bottom bore of Body (10), pirtle end first and press in until it seats.
- Secure Retainer Plate (17) and Cap (19) to Body (10) using two Screws (18).
- Turn Body (10) right side up. Place Diaphragm Assembly (9) on Body (10), aligning six holes in Diaphragm Assembly (9) with six holes in Body (10).
- Center Spring (5) on Diaphragm Assembly (9). Place Retainer (4) on top of Spring (5).
- Using marks made in step 2, align Bonnet Assembly (3) with Body (10). Use six Screws (6) to fasten Bonnet Assembly (3) and Diaphragm Assembly (9) to Body (10). Reinstall Cap (1A) to tamperproof unit.
- Reinstall the relay in accord with installation nstructions in the IOM and follow irstructions in the operation section for placing the relay back in service.



ADJUSTMENTS

There are no field adjustments required.

OPERATION

Relieve pressure on range spring before putting relay into service for the first time. To operate, turn the adjusting screw slowly in a clockwise direction until required positive bias setting is obtained. Turned in this direc-

tion, the screw compresses the range spring causing increased output pressure. For decreased output pressure or negative bias setting, turn the screw counterclockwise.

MAINTENANCE

The relay is easily disassembled for the occasional cleaning or removal of foreign matter. Before this is done, however, shut off valve upstream of the relay to prevent escape of air when relay is disassembled. There is no need to remove the relay from the pipe line; remove the two No. 10-32 screws on the bottom of the unit and pull out the inner valve assembly. Wash inner valve assembly with solvent exercising care to avoid

damaging diaphragms and valve facings. Replace assembly carefully.

The vent hole in the body of the relay should be kept clear. A slight flow of air through this hole is necessary for the proper operation of the relay.

The adjusting screw should be lubricated with Moly-cote type "G" grease.

TROUBLE SHOOTING

PROBLEM	CHECK
Leakage	Body screw tightness Diaphragm
High Bleed	Relief pintle and relief seat for damage or contamination
Difficult to Adjust	Adjusting screw and ball Seal ring lubrication

REPAIR PARTS LIST

Service Kits are available for maintenance of the Model 14 relay.

EA-12128-1	Standard
EA-12128-2	Non-Relieving (N)
EA-12541	Silicone Parts
EA-12542	Viton Parts

LEGAL NOTICE:

The information set forth in the foregoing Installation, Operation and Maintenance Instructions shall not be modified or amended in any respect without prior written consent of Fairchild Industrial Products Company. In addition, the information set forth herein shall be furnished with each product sold incorporating Fairchild's unit as a component thereof.



ISO 9001:2000
FM NO. 25571

www.fairchildproducts.com

IS- 30000014
Litho in USA
Rev. I 06/03