CONTROLS (UK) LTD



Fine Controls have been supplying process controls & instrumentation equipment since 1994, & now serves an ever expanding customer base, both in the UK & globally.

We offer a full range of valve & instrumentation products & services, with our product rangerepresenting leading technologies & brands:

Flow: Flow Meters & Transmitters, Flow Switches, Flow Control Valves & Batch Control Systems

Temperature: Temperature Probes & Thermowells, Temperature ransmitters, Temperature Regulators & Temperature Displays

Level: Level Transmitters & Switches

Pressure: Pressure Gauges & Transmitters, Precision & High Pressure Regulators & I-P Converters, Volume boosters.

Precision Pneumatics: Pressure Regulators, I-P Converters, Volume Boosters, Vacuum Regulators

Valves: Solenoid & Pneumatic Valves. Control Valves & Positioners. Actuated Ball, Globe or Diaphragm Valves & Isolation Valves

Services: Repair, Calibration, Panel Build, System Design & Commissioning





burkert



SIEMENS





A rotork Brand







Honeywell













J Z Z

Fine Controls (UK) LTD, Bassendale Road, Croft Business Park, Bromborough, Wirral, CH62 3QL UK Tel: 0151 343 9966

Email: sales@finecontrols.com

INSTRUCTIONS FOR THE INSTALLATION, OPERATION AND MAINTENANCE OF

FAIRCHILD T6000 SERIES I/P, E/P RACK KIT

GENERAL INFORMATION

The Rack Kit is used to mount TR6000 Transducers into a standard 19" rack or console. Check valves are included in the manifold inlet and outlet ports so that transducer modules may be removed without affecting system operation.

Number of Unitsup to 10 accommodated

Outlet Ports	1/8 NPT vertically on the bottom
and the same of th	1/8 NPT horizontally on the rear
Supply Ports	3/4 NPT on manifold ends
AR STATE	3/8 NPT on manifold rear
Check Valves	inlet and outlet ports

PRINCIPLES OF OPERATION

Fairchild TR6000 Rack Kits include a 10 unit manifold, side brackets and a faceplate to mount in a standard 19" rack.

INSTALLATION

Rack Kits EB-18340-1

(Standard Range) and EB-18368-1 (Extended Range) Figure 1A shows the parts included in the EB-18340-1 (Standard Range) Rack Kit. Figure 1B shows the parts included in the EB-18368-1 (Extended Range) Rack Kit. Figure 1C shows the parts included in the EB-18242-1 Manifold Adapter Kit which allows the user to mount a TR6000 transducer in the manifold.

Rack Kit Assembly EB-18340-1

Obtain Rack Kit EB-18340-1. Consult Figure 1A to be sure that all parts are correct. Obtain manifold assembly (1) and fasten right hand bracket (3) to the manifold (1) using four screws (2). Fasten the left hand bracket (4) to the manifold (1) using four screws (2).

Obtain Front panel (5). Place the assembly of manifold and brackets so that the manifold shelf sits on top of the front panel (5) and the three holes in the manifold (1) are aligned with the three holes in the front panel shelf. Fasten front panel (5) and manifold assembly using three screws (6).

Install EA-18233 pipe plugs (8) in the input locations which will not be used. Use Teflon sealant on the threads. Connect ³/₄ inch air line to one end of the the manifold using proper fittings. The user has the choice of obtaining outputs from the back or the bottom of the manifold assembly. Install the appropriate pneumatic fittings in the manifold.

Slide the assembly into rack or console and secure with four screws. Install manifold adaptor kits EB-18242-1 to the transducer modules per instructions. Install the transducers into the rack/manifold assembly.

Manifold Adapter Kit Installation Figure 1C

Obtain manifold adaptor kit EB-18242-1 and refer to

installation details. Obtain two EB-18150-1 plugs (1) and two EB-130-012-1-70 O Rings (2) from the kit. Install O Ring on plug and insert this assembly in each of the ports on the back of the TR6000 unit.

Obtain two EB-835-5 screws. Insert the screws through EB-18156-1 block and fasten to the bottom front of the TR6000 unit, making sure that the threaded portion of the block faces to the front. Insert captive screw EB-18241-1 into the front of the block and thread through the mating threads. Plug the unit into the manifold assembly. Insert the captive screw into the tapped hole in the shelf of the manifold to hold the transducer in place.

Electrical Connections


Refer to the Installation, Operation and Maintenance Instructions for the T6000 Series.


Rack Kit Assembly EB-18368-1

Obtain rack kit EB-18368-1. Consult Figure 1B to be sure that all parts are correct. Obtain manifold assembly (1) and fasten right hand bracket (3) to the manifold (1) using four screws (2). Fasten the left hand bracket (4) to the manifold (1) using four screws (2).

Obtain front panel (5). Place the assembly of manifold and brackets so that the manifold shelf sits on top of the front panel (5) and the three holes in the manifold (1) are aligned with the three holes in the front panel shelf. Fasten front panel (5) and manifold assembly using three screws (6).

Install EA-18233 pipe plugs (8) in the input locations which will not be used. Use Teflon sealant on the threads. Connect ³/₄ inch air line to one end of the the manifold using proper fittings. The user has the choice of obtaining outputs from the back or the bottom of the manifold assembly. Install the appropriate pneumatic fittings in the manifold.





Slide the assembly into rack or console and secure with four screws. Install manifold adapter kits EB-18242-1 to the transducer modules per instructions. Install the transducer into the rack/manifold assembly.

Manifold Adaptor Kit Installation Figure 1C

Obtain Manifold Adaptor Kit EB-18242-1 and refer to installation details. Rack Muunting Brackets

Obtain two EB-18150-1 Plugs (1) and two EB-130-012-1-70 O Rings (2) from the kit. Install O Ring on the plug and insert this assembly into each of the ports on the back of the TR6000 unit.

Obtain two EB-832-28 screws for the transducer unit. Remove two screws on the bottom front of the unit and insert the screws through the EB-18156-1 block and fasten to the bottom front of the TR6000 unit, making sure that the thread portion of the block faces to the front.

CAUTION

Do not remove the single screw at the bottom back of the transducer.

Insert captive screw EB-18241-1 into the front of the block and thread through the mating threads. Plug the unit into the manifold assembly. Insert the captive screw into the tapped hole in the shelf of the manifold to hold the transducer in place.

Electrical Connections

Refer to the Installation, Operation and Maintenance Instructions for the T6000 Series.


Figure 2 shows the outline dimensions of the TR6000 Rack after assembly. This is a composite drawing showing front panels for both the Standard Range and the Extended Range TR6000 transducers. It also includes dimensions for the right and left hand brackets.

A TR6000 TRANSDUCER TO THE T6000 MANIFOLD.

ITEM	PART NO.	DESCRIPTION	QTY
1	EB-18150-1	PLUG	2
2	EB-130-012-1-70	O-RING	2
3	EB-832-28	SCREW FIL HD 8-32 x 1 3/4	2
4	EB-832-5	SCREW FIL HD 8-32 x 5/16	2
5	EB-18156-1	BLOCK (SEE BITE 2)	1
6	EB-18241-1	CAPTIVE SCREW	1

Figure 1C

SUNTE LISTERS The state of the s



Sure 7

Manifold Adaptor Kit EB-18242-1

